

SETUP GUIDE



MoTeC LTC to CD Dash

Supported Devices

MoTeC LTC / LTCD / LTC NGK / LTCD NGK

CAN Bus Wiring

AEM CD has 2 separate CAN ports. For 3rd party devices, AEM recommends you use AEM CAN Bus 2, whose connections are contained in a 2 pin Deutsch DTM connector. On older harnesses it may be in an unterminated, twisted/shielded flying lead in the dash harness.

MoTeC LTC (CAN HIGH) → AEM CD "CAN 2" Pin 1 (CAN 2+), Gray wire in twisted/shielded pair
MoTeC LTC (CAN LOW) → AEM CD "CAN 2" Pin 2 (CAN 2-), Black wire in twisted/shielded pair

The AEM CD Dash has a software selectable CAN termination resistor. Each network needs 2 terminating resistors, one at each end. The LTC wideband does not have an internal terminating resistor and relies on external Terminating plugs. You can either use those or replace one of them with the internal CD Dash resistor. You must have 2 in total, one at each end of the network.

MoTeC LTC Software Setup

The MoTeC LTC Manager software is not required if using a single LTC or LTCD unit pre-configured by MoTeC. The DBC file provided for the LTC/LTCD by AEM matches this default configuration.

Supported Channels

The AEM CD Dash supports 16 unique channels transmitted from the MoTeC LTC and 32 from the LTCD.

SETUP GUIDE




CH	CD Dash CHANNEL NAME	CH	CD Dash CHANNEL NAME
1	LTC1_BattVolts_raw	17	LTC2_BattVolts_raw
2	LTC1_HeaterDutyCycle_raw	18	LTC2_HeaterDutyCycle_raw
3	LTC1_HeaterFailedtoHeat_raw	19	LTC2_HeaterFailedtoHeat_raw
4	LTC1_HeaterOpenCircuit_raw	20	LTC2_HeaterOpenCircuit_raw
5	LTC1_HeaterShorttoGND_raw	21	LTC2_HeaterShorttoGND_raw
6	LTC1_HeaterShorttoVBATT_raw	22	LTC2_HeaterShorttoVBATT_raw
7	LTC1_Index_raw	23	LTC2_Index_raw
8	LTC1_InternalFault_raw	24	LTC2_InternalFault_raw
9	LTC1_InternalTemp_Raw	25	LTC2_InternalTemp_Raw
10	LTC1_lp_raw	26	LTC2_lp_raw
11	LTC1_lpn_raw	27	LTC2_lpn_raw
12	LTC1_Lambda_raw	28	LTC2_Lambda_raw
13	LTC1_Ri_raw	29	LTC2_Ri_raw
14	LTC1_SensorControlFault_raw	30	LTC2_SensorControlFault_raw
15	LTC1_SensorState_raw	31	LTC2_SensorState_raw
16	LTC1_SensorWireShort_raw	32	LTC2_SensorWireShort_raw

AEM Setup in DashDesign

AEM has provided some pre-configured layouts that can be easily adapted to accept, display and log (if using logging version of CD Dash) the CAN bus channel data from a MoTeC LTC or LTCD. The following steps will show you how to quickly setup your LTC/LTCD to work with an existing AEM DashDesign Layout. A MoTeC LTC was used for this example but the same steps would be used to setup a LTCD / LTC NGK / LTCD NGK.


1. Visit www.aemelectronics.com/forum and scroll down to the CD Dash forum. This is a great place to find answers to all AEM Dash related questions you may have.
2. Open your layout in AEM DashDesign.
3. Click the "Setup" drop down and then select "**Display...**".

SETUP GUIDE




4. Under the "CAN Receive" tab, click the drop down next to "Show" and select "Port 2"

SETUP GUIDE




5. Under the “CAN Receive” tab, select “Import CAN...”

SETUP GUIDE




6. Navigate to the .aemcan (dbc) file for your application. Select the file and click “Open”.

SETUP GUIDE



7. In the CAN Import window you may expand the drop downs and see all of the available CAN channels for your device. You may choose to import all of the channels available or you may select only the channels you wish to display. Just be sure to include "LTC1_Lambda" (and "LTC2_Lambda" if applicable) as a selected channel. For this example we will include all available channels. If using a LTCD, you will see twice as many channels available here. Once you have selected the channels you wish to import, click "Import".

SETUP GUIDE




8. In the Setup Editor under the **"CAN Receive"** tab Port 2, check to make sure the channel names you selected to import are present. If they are not, go back to step 4 and try again. As you can see below all of the


SETUP GUIDE



channels for LTC1 are present.



9. Find the output **"AFR1"** and set its Primary Input to **"LTC1_Lambda"** or select **"Insert"** to create a new channel. Name your new channel LTC1_AFR or similar so it is easy to keep track of. Set the Primary Input to **"LTC1_Lambda"**.




10. Now you need to select the correct conversion for your fuel type and preferred display units. Select the drop down under the **"Operation"** column for AFR1 (or your new channel) and scroll down to **"Convert Lambda to AFR Gas (Stoich 14.65)"** or whichever one matches the stoich ratio of your fuel.

SETUP GUIDE



Output Name	Operation	Primary Input
AFR1	AFR1_scalar	LTC1_Lambda
AFR1ControlTrim	Convert L/100 km to MPG	AFR1ControlTrim_raw
AFRTarget	Convert Lambda to AFR E10 (Stoich 14.39)	AFRTarget_raw
AlarmCoolantTempHigh	Convert Lambda to AFR Ethanol (Stoich 9.00)	CoolantTemp
AlarmFuelPressLow	Convert Lambda to AFR Gas (Stoich 14.58)	FuelPress
AlarmMessage	Convert Lambda to AFR Gas (Stoich 14.65)	CoolantTemp
AlarmOilPressLow	Convert Lambda to AFR Gas (Stoich 14.70)	OilPress
AlarmOilTempHigh	Convert Lambda to AFR Methanol (Stoich 6.47)	OilTemp
Auto_Shift_Light_1	Alarm	EngineSpeed
Auto_Shift_Light_2	Alarm	EngineSpeed

11. Next, open a page in your layout that displays AFR. Double click on the afr value or needle/bar graph you wish to use to display AFR. This should open the “Value Editor”, “Dynamic Needle Gauge Editor” or “Bar Editor” window. Click on the “Input” drop down and select the channel “AFR1” or the channel you created. Click “Ok”. Do this for every location in your layout where you wish to display AFR.



12. Save the layout. Once the layout has been saved connect the dash to your computer and press “Ctrl+U” or “File>Upload to Display...” Once the upload has completed unplug the dash from the computer. You should now be able to view the AFR from your MoTeC LTC/LTCD device on the AEM CD Dash.