




TABLE OF ACRONYMS	
FP	Fuel Pressure
IAT	Intake Air Temp
EOT	Engine Oil Temp
GBT	Gear Box Temp
UEGO	Oxygen Sensor
CLT	Coolant Temp
MAP	Manifold Pressure
TPS	Throttle Position
INJ	Injector
GND	Ground



36-3825 Rev. A
TA2 HEMI ENGINE
HARNESS
COMPONENT
DIAGRAM

All connectors viewed
from REAR unless
otherwise noted