

Infinity TA2 ECU vs Infinity 508 Feature Content

AEM 508 Infinity Full Feature List	AEM TA2 Infinity Feature List
Air Conditioning	Not Included
AirboxTemp	Not Included
AirInletTemp	
Baro Pressure	Not Included
Boost Control	Not Included
Brake Pressure	
Cam/Crank pattern	
CAN (AEMNet)	
Charge Out Pressure	Not Included
Clutch Switch	Not Included
Coil Dwell	
Coolant Pressure	
Coolant Protect	
Coolant Temp	
Cooling Fans	
Crankcase Pressure	
Drive By Wire	Not Included
Engine History	
Engine Displacement	
Exhaust Pressure	Not Included
Flex Content	Not Included
Fuel Pressure	
Fuel Pump	
Fuel Trims Cylinder (2-axis)	
Fuel Trims Cylinder (1-axis)	
Fuel Trims Decel Cut	
Fuel Trims Global	
Fuel Type Selection	
FuelTrim_1 table with selectable axis	Not Included
FuelTrim_2 table with selectable axis	Not Included
Idle	
Idle Stepper output	
Ignition Map	
Ignition Map load axis selection	
Ignition Sync	
Ignition Trims Cylinder	
Ignition Trims Global	
Ignition Trims Idle	
IgnTrim_1 Table with selectable axis	Not Included
IgnTrim_2 Table with selectable axis	Not Included
Injector Duty Limit	
Injector Flow Primary	

Injector Flow Secondary	Not Included
Injector Timing	
Kill Switch	
Knock	Not Included
Lambda Target FB	
LambdaFB external input (Lambda3-4)	Not Included
LambdaFB activation criteria	
LambdaFB gains	
LambdaFlexBlend Table with selectable axis	Not Included
LambdaTrim_1 Table with selectable axis	Not Included
Launch Antilag	Not Included
Launch Ramp Timer	Not Included
Launch Timer	Not Included
Lean Protect	
Limiter -2Step	Not Included
Limiter -3Step	Not Included
Limiter-Shift Cut	Not Included
MAF	Not Included
Main Relay output	
Main Rev Limit	
MIL driver warning lamp	
MIL manual trigger switch	Not Included
Nitrous -Single Stage	Not Included
Oil Pressure	
Oil Pressure Protect	
Oil Temp	
Oil Temp Protect	
Onboard UEGO-Lambda1	
Onboard UEGO-Lambda2	Not Included
Over Boost Cut	Not Included
Rolling Launch	Not Included
Set Throttle Range	
Shift Switch	Not Included
Spark Load Axis selection	
Steering Angle	
Tacho Output	
Traction Control	Not Included
Trans Temp	
Turbo Speed	Not Included
USB Log Switch	Not Included
USB Logging	
User Configurable High Side outputs	Not Included
User Configurable Lowside outputs	Not Included
VE Table	
VE Load Axis selection	
VE_Blend Table with selectable axis	Not Included
Vehicle Speed	

VTEC	Not Included
VVT	Not Included
WallWetting with selectable axis	
WallWetting2 with selectable axis	
X-Series CAN	